

Example: Mixed multiplier panel milled

- The panel design should always be checked with your assembly partner, pay attention to fiducial marks and mounting holes!
- Minimum space between tracks / copper and milling edge: 200µm!
- Diameter of milling tool, always 2.4mm!
- Minimum space between PCBs: 10mm!
- Bridges are placed by us!
- If you place the bridges by yourself, use a width of 1 - 1.5mm!
- We recommend a frame of 5 - 10mm for better handling!

