

Example: Complex panel scored

- The panel design should always be checked with your assembly partner, pay attention to fiducial marks and mounting holes!
- Minimum space between tracks / copper and scoring edge: 500 μ m!
- Spacing between the single boards: 0.0mm!
- Define outlines with 0.01mm or 1mil!
- We suggest a frame of 5 - 10mm for better handling!

		Recommended: Surrounding frame of approx. 5-10mm.	{
		Space between copper and scoring edge: min.500 μ m 0.0mm spacing, outline: 0.01mm (or 1mil)	