

Example: Simple panel milled

- The panel design should always be checked with your assembly partner, pay attention to fiducial marks and mounting holes!
- Minimum space between tracks / copper and milling edge: 200µm!
- Diameter of milling-tool, always 2.0mm!
- Bridges are placed by Multi-CB, i.e. the mere milling contour with 2.0mm in your data is sufficient!
- If you place the bridges by yourself, use a width of 1 - 1.5mm!
- We recommend a frame of 5 - 10mm for better handling!

